

Thank you for your purchase - and for supporting a small business. ❤️

Flooring cutout: trace the included flooring insert/tray on your flooring and cut to that outline, for reference here are the suggested sizes to cut your flooring:

4x10	65 mm	212 mm
3x10	41 mm	212 mm
4x12	63 mm	262 mm

Step-by-step

1. **Cut the flooring** using the included insert as a template (recommended) or the measurements above.
2. **Check flooring thickness:** the tray depth is **22 mm**.
 - If your flooring is ~22 mm thick, **no spacer needed**.
 - If thinner, use a spacer/shim thickness of: **22 mm – your flooring thickness**.
3. **Snap the tray into the vent body:** hook the **bottom two pins first** (tray on an angle), then press firmly until the **top two pins click**.
4. **Place your flooring piece into the tray**, then **drop the vent into the opening**.

Troubleshooting

- If it doesn't sit flush, **the tray usually isn't fully clicked in** — remove and press until it snaps.

Need help?

Email support@khansupply.co - you'll get a human reply ASAP.