



MAINTENANCE GUIDE

PRE-OILED FLOOR

Dust may be removed using a vacuum cleaner, dry cloth or soft broom. Use of the following products is mandatory because they are specially designed and made for preoiled ACCENT™ flooring. Use of commercial detergents or other products will damage your floor.

Regular maintenance

Tikal, El Dorado, Guban, Habano, Babylon, Petra, Larzac, Atlantis, Tulum and Atacama

- 1) Vacuum or sweep floor to remove dust and sand.
- 2) Spray cleaner (Oilnet+) on the floor and spread evenly in thin coats using a flat, microfiber mop.
- 3) Allow to dry.

Maintenance as required (monthly)

- 1) Vacuum or sweep floor to remove dust and sand.
- 2) Spray the Oilnew+ product on the floor and spread evenly in thin coats using a flat, microfiber mop.
- 3) Allow to dry.

This product line made of oil and natural resin complies with regulations governing human health and environmental protection.