












552-972BK TENLEY ASSEMBLY INSTRUCTIONS /
INSTRUCTION D'ASSEMBLAGE

 Ax1	 Cx1	 Ex5	 Gx1	 Ix1
 Bx1	 Dx1	 Fx1	 Hx1	 Jx1
				 Kx1

