

Riverby® Top-mount Kitchen Sink K-5872-1A1

Features

- 27-inch minimum base cabinet width.
- Single bowl.
- 9" depth provides generous workspace.
- Single faucet hole.
- Bowl slopes 2 degrees toward drain to minimize water pooling.
- Offset drain increases workspace in the sink and storage space underneath.
- Includes stainless steel sink rack.
- Small size fits compact spaces.

Material

KOHLER® enameled cast iron.

Installation

Top-mount.

Recommended Products/Accessories

K-6238 Sink Rack K-8801 Sink Strainer K-8799 Sink Strainer K-23726 Drain treatment K-23725 Cast iron cleaner

Optional Products/Accessories

K-6194 Utility Rack With Soaking Cup K-6239 Colander with Cutting Board K-6246 Cutting Board 1054375 Undermount sink kit, 23" K-11352 Disposal Flange with Stopper K-9000 P-Trap

Included Components

Product consists of: K-6238 Sink Rack



Codes/Standards

ASME A112.19.1/CSA B45.2

KOHLER® Enameled Cast Iron Kitchen Sink Lifetime Limited Warranty

See website for detailed warranty information.

Available Colors/Finishes

Color Codo Description


Color tiles intended for reference only.

Color	Code	Description
	0	White
	FF	Sea Salt™
	96	Biscuit
	47	Almond
	FD	Cane Sugar™
	95	Ice™ Grey
	G9	Sandbar
	K4	Cashmere
	20	Suede
	KA	Black 'n Tan
	7	Black Black™





Riverby® Top-mount Kitchen Sink K-5872-1A1



(46 mm) (110 mm)

1-13/16"

4-5/16"

Technical Information

All product dimensions are nominal.

Bowl configuration: Single
Installation: Top-mount
Min. base cabinet 25" (635 mm)

width:

Bowl area (Only): Length: 22-1/4" (565 mm)

Width: 15-13/16" (402 mm) Bowl depth: 9" (229 mm)

1-1/2" OD

Number of deck holes: 1

Faucet hole(s): 1-3/8" (35 mm)
Drain hole: 3-7/8" (98 mm)

Template: 1172565-7, required, included

Notes

Install this product according to the installation instructions.

NOTICE: Countertop manufacturer or cutter must use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

IMPORTANT! Use of the colander, wood cutting board, and utility rack requires the "reveal" cutout option on the cutout template.

