



Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at <https://tiny.cc/SunnydazeContact>
















MERANTI WOOD STORAGE BENCH FRN-893

Assemble components on a soft, clean surface to avoid damaging the finish. Save this manual for future reference.





440
pounds
200 kg
Weight Capacity



No.	PARTS	QTY.
A	 Backrest	1
B	 Right Arm	1
C	 Left Arm	1
D	 Front Panel	1
E	 Back Panel	1
F	 Lid	1
G	 Bottom Panel	1
H	 JCBC M6x60 Grub Screw	8
I	 JCBC M6x40 Bolt	4
J	 JCBC M6x16 Bolt	12
K	 Coupling Nut	8
L	 Curved Washer	8
M	 Hinge (L&R)	2
N	 Hex Key	1
O	 Spanner	1

! WARNING !

CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.



Tip: Always fully insert the hex key inside the designated notch of the bolt.

If the hex key is not fully inside the notch, the hex key could slip out, causing damage to the bolt head. Repeated hex key slipping will cause the notch to become rounded, making it difficult or impossible to tighten the bolt with the hex key.


ASSEMBLY

Read carefully and understand assembly before beginning.

Do not fully tighten bolts until all components have been loosely assembled.

STEP 1

B: 1
C: 1
H: 8




- Insert 4x JCBC M6x60 Grub Screw (H) into the inside of each Arm Panel (B, C).

Do not fully tighten any hardware until after Step 6 is complete.

STEP 2

D: 1
E: 1
K: 8
L: 8




- Ensuring the pre-drilled holes face inward, align Front Panel (D) and Back Panel (E) over the grub screws.
- Place Curved Washer (L) over grub screws, as shown, then secure by hand-tightening Coupling Nut (K).

Do not fully tighten any hardware until after Step 6 is complete.

STEP 3

G: 1




- Place Bottom Panel (G) inside the storage box, as shown.

Do not fully tighten any bolts until after Step 6 is complete.

STEP 4

M: 2
J: 6




- Fasten the bottom of right-side Hinge (M) to the inside of the storage box by hand-tightening 3x JCBC M6x16 Bolt (J), as shown.
- Repeat this step on the left side of the storage box.

Do not fully tighten any bolts until after Step 6 is complete.

STEP 5


F: 1
J: 6



- Align Lid (F) with the top of Hinge (M) and secure by hand-tightening 3x JCBC M6x16 Bolt (J)
- Repeat this step on the left side of the storage box lid.
Do not fully tighten any bolts until after Step 6 is complete.

STEP 6

A: 1
I: 4



- Affix Backrest (A) to the arms using 4x JCBC M6x40 Bolt (I), as shown.

Fully tighten all hardware after this step is complete.

Care & Maintenance

SAFE USE: Only use on a flat, level surface. Do not stand on the storage bench.

INSPECT: Periodically check assembly points and tighten fittings as necessary.

CLEANING: Identify the direction of the woodgrain. Following the direction of the woodgrain, wipe surfaces with a soft, dry cloth. Do not use harsh chemicals or abrasive materials or a pressure washer to clean.

COVER: When not in use, cover furniture with a breathable cover to help protect it from the harmful effects of sunlight, inclement weather, dust build-up, and collecting debris.

WINTER CARE & STORAGE: Protect this item from inclement weather, especially ice and snow. Move to a cool, dry indoor location. Covering while in storage is recommended to help prevent dust build-up.

MAINTENANCE: If left untreated, the wood may weather. A suitable wood stain or oil may need to be applied yearly.

WARNING: THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE USE OF CHEMICAL TREATMENTS OR PROTECTIVE COATINGS.

! SAFETY STATEMENTS & WARNINGS !

- Do not exceed the weight capacity of the bench.
- Do not let children to use the lid or play inside the storage box.
- Do not use this item in the proximity of open flame or flammable/combustible chemicals.
- Keep this unit a safe distance from heat sources such as fire pits, patio heaters, and grills.
- Do not use harsh chemicals or abrasive materials to clean this unit.
- This product is for residential use only; institutional or commercial use will void this warranty.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.