

Working with your Workmate® Work Center

The Work Center is a vise and workbench all in one. Its basic design and special features help you perform a complete range of workshop tasks from the simplest to the most complicated. The heart of the Work Center is in the action of the two parallel vise jaws. The two vise handles adjust the jaws to a maximum of 4 1/2 inches (114mm) jaw opening. Because each handle works independently, the opening can be tapered from 0 inches to 5 inches (127mm) maximum. Use of the swivel pegs in the appropriate vise holes extends the vise capacity of the Work Center up to 10-1/2 inches (266mm) parallel clamping and 22-1/2 inches (570mm) when objects are held diagonally. The Work Center is a useful sawhorse and holds material securely. Sawing tubular pieces is easy when they are held horizontally in the specially designed "V" grooves running along the face of the vise jaws. Vertical "V" grooves in the vise jaws permit rigid vertical grasping of tubular objects.

NOTE: Place your foot on the bracket of the Work Center to steady it.
DO NOT USE AS A STEP.

ACCESSORIES

Recommended accessories for use with your tool are available from your local dealer or authorized service center. If you need assistance regarding accessories, please call: **1-800-544-6986**.

⚠ WARNING: The use of any accessory not recommended for use with this tool could be hazardous.

SERVICE INFORMATION

All Black & Decker Service Centers are staffed with trained personnel to provide customers with efficient and reliable power tool service. Whether you need technical advice, repair, or genuine factory replacement parts, contact the Black & Decker location nearest you. To find your local service location, refer to the yellow page directory under "Tools—Electric" or call: **1-800-544-6986** or visit **www.blackanddecker.com**

FULL TWO-YEAR HOME USE WARRANTY

Black & Decker (U.S.) Inc. warrants this product for two years against any defects in material or workmanship. The defective product will be replaced or repaired at no charge in either of two ways.

The first, which will result in exchanges only, is to return the product to the retailer from whom it was purchased (provided that the store is a participating retailer). Returns should be made within the time period of the retailer's policy for exchanges (usually 30 to 90 days after the sale). Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges.


The second option is to take or send the product (prepaid) to a Black & Decker owned or authorized Service Center for repair or replacement at our option. Proof of purchase may be required. Black & Decker owned and authorized Service Centers are listed under "Tools-Electric" in the yellow pages of the phone directory.

This warranty does not apply to accessories. This warranty gives you specific legal rights and you may have other rights which vary from state to state or province to province. Should you have any questions, contact the manager of your nearest Black & Decker Service Center. This product is not intended for commercial use.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call **1-800-544-6986** for a free replacement.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, check country specific warranty information contained in the packaging, call the local company or see the website for warranty information.

Imported by
Black & Decker (U.S.) Inc.,
701 E. Joppa Rd.
Towson, MD 21286 U.S.A.



See 'Tools-
Electric'
- Yellow Pages -
for Service &
Sales 