

MD-GRR INSTALLATION



INSTALLATION INSTRUCTIONS

Modern Grab Bar Installation

1. Use a stud finder to accurately locate the center of the stud.
2. Remove Cap on each end of post to allow opening for mounting screw.
3. Place Grab Bar on wall at desired mounting location and mark drill hole location with pencil. Mark is made by inserting pencil through the end post and marking location of small hole at bottom of post.
4. Drill 9/64" hole into the wall studs.
5. Mount and position end posts to the drilled holes.
6. Fasten the Grab Bar to mounting surface using #10 Wood Screw supplied and tighten.
7. Replace Cap on posts.

