



# QO® Load Centres, Class 1100

## Centres de distribution QO®, classe 1100

Retain for future use. / À conserver pour usage ultérieur.

### INTRODUCTION

This bulletin contains instructions for the installation and operation of QO® load centres for Canada manufactured by Square D.

E  
N  
G  
L  
I  
S  
H

### **⚠ DANGER**


#### HAZARD OF ELECTRIC SHOCK, BURN, OR EXPLOSION

- This equipment must be installed and serviced only by qualified electrical personnel.
- Turn off all power supplying this equipment before working on or inside equipment.
- Always use a properly rated voltage sensing device to confirm all power is off.
- Replace all devices, doors, and covers before turning on power to this equipment.
- Do not allow petroleum-based paints, solvents, or sprays to contact the nonmetallic parts of this product.
- Before starting a wiring installation or addition, consult a local building or electrical inspector for current Canadian Electrical Code requirements. Local codes vary, but are adopted and enforced to promote safe electrical installations. A permit may be needed to do electrical work, and some codes may require an inspection of the electrical work.
- This equipment may not be suitable for use in corrosive environments present in agricultural buildings. See NEC 547 or CEC 2-400.

**Failure to follow these instructions will result in death or serious injury.**

### PREPARATION

1. Determine the wiring or conduit requirements for the main and branch circuits, as required by local electrical codes.
2. Select the proper cable clamp, or use other approved methods for securing the cable or conduit to the enclosure.
3. Remove the line termination area barrier.  
See Figure 1.
  - a. Remove the retaining screws.
  - b. Remove the barrier. (Barrier must be replaced before energizing any circuit breakers.)



**Figure 1: Removing the Barrier**

*NOTE: Load centres used as service entrance panels must have a barrier between the line termination and load termination area. All Square D main breaker load centres include a factory installed barrier.*

4. Remove the appropriate knockouts required for installation of cable clamps or conduit (Table 1). To remove the knockouts, see Figure 2.






Figure 2: Removing the Knockouts

**Table 1: Bolt-On Conduit Hubs for Outdoor Load Centres (order separately)**

Conduit	Hub No.
3/4 in.	B-075
1 in.	B-100
1-1/4 in.	B-125
1-1/2 in.	B-150
2 in.	B-200
2-1/2 in.	B-250

## BOX MOUNTING

### Surface Mounting (Indoor or Outdoor)

Fasten the box to the wall with screws or nails. Use all pre-cut holes in the back of the box. See Figure 3.

### Flush Mounting (Indoor Box Only)

1. Remove the small mounting knockouts on the side of the box. See Figure 4.
2. Position the load centre so front edge of enclosure is flush with finished wall.
3. Nail or screw through the small knockouts on the enclosure sides.

## MAIN CIRCUIT BREAKER OR MAIN LUG WIRING

1. Pull the conductors into the box. Use approved wire clamps, conduit bushings, or other approved methods to secure the conductor to the box and prevent damage to the conductor insulation.
2. Connect the main and neutral wires.
  - a. Install the main and neutral wires according to load centre wiring diagram.
  - b. Connect the service ground, equipment grounding wire, or both as required by local electrical code.
  - c. Torque each connection to the value specified on the load centre wiring diagram attached to the box.




Figure 3: Surface Mounting






Figure 4: Flush Mounting

3. If the main breaker load centre is not used as a service entrance panel, remove the brass neutral bonding screw as shown in Figures 5 and 6.



**Figure 5: Single-phase load centre**



**Figure 6: Three-phase load centre**

E  
N  
G  
L  
I  
S  
H

4. Reinstall the line termination area barrier (for load centres used as service entrance panels). Secure barrier with retaining screws and torque screws to 35 lb-in (4 N·m).

## BRANCH CIRCUIT BREAKER INSTALLATION AND REMOVAL

### **CAUTION**

#### **HAZARD OF EQUIPMENT DAMAGE**

Use only circuit breakers and accessories manufactured by Square D.

**Use of other components voids the warranty, may void the CSA certification, and can result in property loss or personal injury.**

### Installation

1. Determine the wiring or conduit requirements for the branch circuit.
2. Turn OFF the circuit breaker.
3. Install the wire terminal end of the circuit breaker onto the mounting rail and push inward until the plug-on jaw fully engages the bus bar connector. Keep the bottom of the circuit breaker case against the mounting rail.
4. Remove the wire insulation from the branch wire as required. Install the branch wire into the load terminal of the branch circuit breaker.
5. Torque each branch circuit breaker connection to the value specified on the circuit breaker.
6. Torque each neutral and ground connection to the value specified on the load centre wiring diagram attached to the box.

## Removal

1. Turn OFF the circuit breaker. Remove the wires.
2. To disconnect the plug-on jaw from the connector and mounting rail, pull the circuit breaker outward until it disengages from the mounting rail. See Figure 7.




Figure 7: QO Branch Circuit Breaker

## INSTALLING THE COVER

1. Remove the cover twistouts. See Figure 8.
  - a. Remove only enough twistouts to match the number of circuit breakers being installed.
  - b. Twist out with pliers at the centre of the twistout.
  - c. Close all unused open spaces in the cover using filler plates, as listed on the cover directory label.
2. Attach the French translation label, supplied with the load centre, to the rear of the cover. See Figure 9.
3. Identify the branch circuits on the directory label.
4. Install the cover using screws provided.




Figure 8: Twistout Removal

## ENERGIZING THE LOAD CENTRE

1. Before energizing the load centre, turn OFF the main and all branch circuit breakers.
2. After power is turned ON to the load centre, first turn ON the main circuit breaker and then turn ON the branch circuit breakers.




Figure 9: Label Locations on Load Centre Cover

For questions about this equipment, call the Customer Information Centre at Square D Canada at 1-800-565-6699 between 8:00 a.m. and 8:00 p.m. weekdays (Eastern Time).

Square D Company  
19 Waterman Avenue  
Ontario, Canada M4B 1Y2  
1-800-565-6699

Electrical equipment should be serviced only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material. This document is not intended as an instruction manual for untrained persons.

## INTRODUCTION

Ce manuel contient les directives d'installation et de fonctionnement des centres de distribution QO fabriqués par Square D.

## ⚠ DANGER


### RISQUE D'ÉLECTROCUTION, DE BRÛLURES OU D'EXPLOSION

- L'installation et l'entretien de cet appareil ne doivent être effectués que par du personnel qualifié.
- Coupez l'alimentation à cet appareil avant d'y travailler.
- Utilisez toujours un dispositif de détection de tension à valeur nominale approprié pour s'assurer que toute l'alimentation est coupée.
- Replacez tous les dispositifs, les portes et les couvercles avant de mettre cet appareil sous tension.
- Évitez que les peintures, les solvants ou les vaporisateurs à base de pétrole viennent en contact avec les pièces non-métalliques de ce produit.
- Avant de commencer l'installation ou l'addition du câblage, consultez un inspecteur local spécialisé dans le bâtiment ou les installations électriques pour connaître la réglementation en vigueur prescrite par le CCÉ. Les codes locaux varient mais sont adoptés et appliqués pour assurer des installations électriques sans danger. C'est peut-être nécessaire d'avoir un permis pour exécuter des travaux sur des circuits électriques et certains codes peuvent exiger que le travail électrique accompli soit inspecté.
- Cet appareil peut ne pas convenir à une utilisation en milieux corrosifs présents dans les bâtiments agricoles. Voir le NEC (É.-U.) 547 ou CCÉ 2-400.

**Si ces précautions ne sont pas respectées, cela entraînera la mort ou des blessures graves.**

## PRÉPARATION




1. Déterminer les exigences de câblage ou de conduit pour les circuits principaux et de dérivation, comme requises par les codes électriques locaux.
2. Sélectionner la pince de câble appropriée ou utiliser d'autres techniques approuvées pour attacher le câble ou le conduit au coffret.
3. Retirer la cloison d'isolation de la zone de terminaison de ligne. Voir la figure 1.
  - a. Retirer les vis de retenue.
  - b. Retirer la cloison du boîtier. (Remettre la cloison en place avant d'alimenter les disjoncteurs).



**Figure 1 : Retrait de la cloison**

**REMARQUE :** Les centres de distribution utilisés comme panneaux d'entrée de service doivent être munis d'une cloison entre les zones de ligne et de charge. Tous les centres de distribution ayant un disjoncteur principal Square D comprennent une cloison installée à l'usine.

4. Retirer les débouchures appropriées pour pouvoir installer les pinces ou le conduit de câble (tableau 1). Pour retirer les débouchures, voir la figure 2.



**Figure 2 : Retrait des débouchures**

**Tableau 1 : Manchons de conduit à boulonner pour centres de distribution extérieurs (commander séparément)**

Conduit	N° de manchon
3/4 po	B-075
1 po	B-100
1-1/4 po	B-125
1-1/2 po	B-150
2 po	B-200
2-1/2 po	B-250


## MONTAGE DU BOÎTIER

### Montage en surface (intérieur et extérieur)

Fixer le boîtier au mur à l'aide des vis ou des clous. Utiliser tous les trous pré-coupés au dos du boîtier. Voir la figure 3.

### Montage encastré (pour boîtier intérieur seulement)


1. Retirer les petites débouchures de montage sur le côté du boîtier. Voir la figure 4.
2. Positionner le centre de distribution pour que le bord avant du coffret soit au même niveau que le mur fini.
3. Clouer ou visser par les petites débouchures des côtés du coffret.



**Figure 3 : Montage en surface**

## CÂBLAGE DU DISJONCTEUR OU DE COSSE PRINCIPAL

1. Tirer les conducteurs pour les mettre dans le boîtier. Utiliser les serre-fils, les raccords de conduit homologuées ou d'autres méthodes approuvées pour fixer le conducteur au boîtier et éviter d'endommager l'isolation du conducteur.
2. Connecter le conducteur principal et le conducteur du neutre.
  - a. Installer le conducteur principal et le conducteur du neutre selon le schéma de câblage du centre de distribution.
  - b. Connecter la mise à la terre de service, le conducteur de m.à.l.t. de l'appareil ou les deux de la façon exigée par les codes locaux d'électricité.
  - c. Serrer chaque connexion à la valeur spécifiée sur le schéma de câblage du centre de distribution attaché au boîtier.



**Figure 4 : Montage encastré**

- Si le centre de distribution à disjoncteur principal n'est pas utilisé comme panneau d'entrée de service, retirer la vis de fixation du neutre en laiton comme indiqué aux figures 5 et 6.




Figure 5 : Centre de distribution monophasé




Figure 6 : Centre de distribution triphasé

- Réinstaller la cloison d'isolation de la zone de terminaison de ligne (pour les centres de distribution utilisés comme panneaux d'entrée de service). Fixer la cloison à l'aide des vis de retenue et serrer les vis à 4 N·m (35 lb-po).

## INSTALLATION ET DÉMONTAGE DU DISJONCTEUR DE DÉRIVATION

### **ATTENTION**

#### RISQUE DE DOMMAGES MATÉRIELS

N'utilisez que les disjoncteurs et kits fabriqués par Square D.


**L'utilisation d'autres composants annule la garantie, risque d'annuler la classification CSA, et peut entraîner des dommages matérielles ou des blessures.**

### Installation

- Déterminer les exigences du câblage ou du conduit pour le circuit de dérivation.
- Mettre le disjoncteur hors tension.
- Installer l'extrémité des bornes des câbles du disjoncteur sur le profilé et pousser vers l'intérieur jusqu'à ce que la mâchoire enfichable s'engage complètement sur le connecteur de la barre bus. Maintenir la partie inférieure du boîtier du disjoncteur contre le profilé.
- Retirer l'isolation du fil d'artère comme requis. Installer le fil d'artère dans la borne de charge du disjoncteur de dérivation.
- Serrer chaque connexion de disjoncteur de dérivation à la valeur spécifiée sur le disjoncteur.
- Serrer chaque connexion à la valeur spécifiée dans le schéma de câblage du centre de distribution attaché au boîtier.

## Démontage

1. Mettre le disjoncteur hors tension. Retirer les fils.
2. Pour déconnecter la mâchoire enfichable du connecteur et du profilé, tirer le disjoncteur vers l'extérieur jusqu'à ce qu'il se dégage du profilé. Voir la figure 7.



## INSTALLATION DU COUVERCLE

1. Retirer les plaquette à tordre du couvercle. Voir la figure 8.
- a. Ne retirer qu'un nombre de plaquettes correspondant au nombre de disjoncteurs à installer.
- b. Tourner en plaçant les pinces au centre de la plaquette.
- c. Couvrir tous les espaces ouverts du couvercle inutilisés avec des plaques de remplissage, conformément à l'étiquette de répertoire du couvercle.
2. Fixer l'étiquette en français, fournie avec le centre de distribution, au dos du couvercle. Voir la figure 9.
3. Identifier les circuits de dérivation sur l'étiquette de répertoire.
4. Installer le couvercle à l'aide des vis fournies.

## MISE SOUS TENSION DU CENTRE DE DISTRIBUTION

1. Avant de mettre sous tension le centre de distribution, mettre hors tension le disjoncteur principal et tous les disjoncteurs de dérivation.
2. Après la mise sous tension du centre de distribution, mettre d'abord le disjoncteur principal sous tension, puis les disjoncteurs de dérivation.

Schneider Canada Inc.  
19 Waterman Avenue, M4B 1 Y2  
Toronto, Ontario  
1-800-565-6699  
[www.schneider-electric.ca](http://www.schneider-electric.ca)

Pour toutes questions concernant cet appareil, appeler le Centre de renseignements aux clients de Square D (É.-U.) au 1-800-565-6699 entre 8h 00 et 20h 00, les jours de la semaine (EST).

L'entretien du matériel électrique ne doit être effectué que par du personnel qualifié. Schneider Electric n'assume aucune responsabilité des conséquences éventuelles découlant de l'utilisation de ce matériel. Ce document n'est pas destiné à servir de manuel d'utilisation aux personnes sans formation.

# Product Warranty

## Square D/Schneider Electric Residential Products Limited Warranty

### A. Limited Warranties

Square D brand Loadcentres and Square D QO brand Circuit Breakers - Schneider Canada warrants its Square D QO brand branch circuit breakers to be free from defects in material and workmanship under normal care and proper usage in a residential installation, for the lifetime of the loadcentres in which it is installed. QO brand loadcentres are also covered under the same lifetime warranty. If the QO brand circuit breaker or QO brand loadcentre fails within the warranty period because of a defect in material or workmanship, Schneider Canada will replace the defective QO breaker or QO loadcentre free of charge upon following the notice procedures below and return of the product to place of purchase.

### B. Exclusive Remedy

The repair and/or replacement of defective products are your sole and exclusive remedy.

### C. Warranty Redemption and Exclusions

1. Schneider Canada must be given prompt written notice of any defect or failure of any product covered by these limited warranties at the following address:

Schneider Electric - Canadian Returns Centre

2501 Stanfield Road , Mississauga, Ontario, L4Y 1R6.

For warranty redemption, you must return the product to Schneider Canada at the above address.

2. Any product returned under these limited warranties, if shipped, must be sent freight costs prepaid. Schneider Canada will deliver repaired or replaced products to buyer, freight costs prepaid. Repaired or replaced products shall be warranted hereunder only for the unexpired portion of the original warranty period. This warranty does not include costs or reimbursement for labour.

Any limited warranties granted or liabilities assumed here under will not apply to products that have been damaged, altered, repaired or operated otherwise than in conformity with the requirements for safe operation and maintenance.

For your safety and to provide optimum short circuit protection, Schneider Canada recommends that you use only the Square D circuit breakers identified on the loadcentre or combination service entrance device label or wiring diagram.

### D. Disclaimer of All Other Warranties

EXCEPT FOR THE EXPRESS WARRANTY SET FORTH ABOVE OR ANY WARRANTIES IMPLIED BY LAW, SCHNEIDER CANADA MAKES NO OTHER EXPRESS OR IMPLIED WARRANTIES. TO THE FULLEST EXTENT PERMITTED BY LAW, SCHNEIDER CANADA DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING ALL WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR PURPOSE. THE FOREGOING DISCLAIMER MAY NOT APPLY TO YOU DEPENDING UPON THE PRODUCT YOU PURCHASE, THE APPLICATION AND USE OF YOUR PRODUCT, OR YOUR STATUS AS A CONSUMER. TO THE EXTENT YOU ARE ENTITLED TO RECOVER UNDER AN IMPLIED WARRANTY, THE DURATION OF THAT IMPLIED WARRANTY SHALL BE THE PERIOD OF THE EXPRESS LIMITED WARRANTY SET FORTH ABOVE.

### E. Limitation of Liability

Schneider Canada expressly disclaims any and all liability to you for any consequential or incidental damages, damages for loss of use, loss of profits, income or revenue, loss of time or inconvenience, loss or damage to associated equipment, damages to tangible or intangible property, other than the equipment covered by this limited warranty, cost of substituted or replacement equipment other than as expressly warranted, damages associated with excessive over voltages, obsolescence, abuse, misuse, non-authorized modification, alteration or catastrophic events, or any other incidental, consequential or special damage arising out of the use of the products. Schneider Canada shall not be liable for indirect, special, incidental or consequential damages with respect to the sale of the products, including any lost revenue or profits, consequential and/or incidental damages, business interruption or damage to business reputation, regardless of the theory upon which any claim may be based, including any statutory, tort contract or insurance subrogation causes of action or claims. In no event will Schneider Canada entire liability to you, including any liability in the event the exclusive remedy set forth in this agreement fails of its essential purpose, exceed the purchase price for the affected products.