

# Instructions for Installing Shower Panel



## Tools Needed:

Adjustable wrench, Bathroom rated silicone sealant, Caulk gun, Tape measure, screwdriver, Pipe cutter

**WARNING:** You must turn off the cold and hot water supply to the location of installation before starting the installation.

## Mounting Your Showerhead

Install the rubber washer onto the showerhead and install onto the shower arm.

## Steps for Mounting the Shower Panel:

1. Find the package containing the mounting brackets, screws, and wall anchors first. These will be utilized in the procedure that follows.
2. With a center line, indicate the location of the shower panel's center. (This is typically in the middle of the supply lines for the plumbing.)
3. Holding the shower panel at the proper height and placement on the middle line, make marks on its bottom and center. This will serve as a point of reference for the measurements of the shower panel's bottom and the other measurements needed to position the mounting brackets.

4. The unit should be placed on the ground with its back upward. Locate the unit's two built-in hanging straps.
5. The following guidelines will help you place the mounting brackets-
  - a) Units with two single brackets use four mounting brackets. (Use two for the top straps and two for the bottom straps.)
  - b) Determine the distance between the upper and lower straps. This is the "X" dimension. Measure from the top or bottom of the strap.
  - c) Determine the distance between the outermost dimensions from the bottom of the top strap to the bottom of the shower panel. Measure this to get the "Y" dimension.
  - d) Measure and mark the distance "Y" from the fiducially mark (made when the shower panel is against the wall) to the outside bottom of the shower panel. ("Y" is the distance from the bottom of the top strap to the bottom outside of the shower screen.) Mark this.
  - e) Place the second mark a few inches away from the mark you just made. This second mark should be horizontal. Using a spirit level, draw a horizontal line through these two marks.
  - f) f. The two mounting brackets should be evenly spaced around the centerline (each strap requires two mounting brackets). (Tip: To determine the distance between the two brackets, divide the width of the shower screen by 2.) Divide the distance between the two brackets to determine the distance between each bracket and the centerline. Mark the distance between the two mounting brackets.
  - g) Keep the mounting bracket flat against the wall by aligning the mounting holes from the center line over the bracket location marks. The mounting holes should face the shower floor.
  - h) This mounting bracket should be aligned so that the bend in the bracket is aligned with the horizontal line you drew earlier. While doing so, make sure the mounting holes are centered on the marks you made on the bracket location.
  - i) Mark her two mounting holes on the mounting bracket.
  - j) Repeat this process for the other mounting bracket and you will have successfully marked the locations for both the top brackets.
  - k) Repeated this process for the other mounting brackets and successfully marked the location of the top two brackets.
  - l) Use her one position of the upper mounting bracket as a reference for the following measurements. Measure and mark the distance "X" straight down from the top mounting hole. ("X" is the distance between the two mounting tabs.)
  - m) Repeat this process for the other top mounting bracket location.

- n) Place the third mounting bracket using one of the two marks on her last. Align the top mounting hole of the bracket with the center of the mark. Make sure the mounting bracket is vertical and mark both mounting holes.
- o) Repeat the last step for the fourth and final bracket.
- p) Drill each hole location. Use a 5/16 inch diameter drill bit suitable for the wall.
- q) Insert the plastic anchor into the drilled hole.
- r) Use a screwdriver or drill bit to attach the mounting bracket to the wall with the screws provided.